

## **AGRIMATE MANUAL CUM BATTERY SPRAYER**

GP-BSDP-20MS+



Before Operating this machine please read instructions Manual carefully **Desclaimer:** Due to Constatnt upgradation, features & Specifications are subject to change without prio notice

Dear Sir/Madam,

Thank you for choosing Agrimate product. You are the proud owner of high technology and durable machine. Trust that our franchisee/dealer installed the product and explained you about the usage and service instructions. Please visit our authorised dealer for you future requirement of our other equipments, genuine spares, accessories and service. Service coupons are attached with this manual and you can avail free service.

### About Ratnagiri

We import and market of high quality of agriculture wide range of equipment's Which we are selling through our authorized franchisee or dealer network. We are in this field from past 20 years serving the former community. For further details, you may please visit our website **www.agrimart.in** 

#### **MAINTENANCE**

- 1. Each time after using this sprayer, it must be charged to maintain inside power and to avoid short working life.
- 2. When doing change or discharge, please assure that you have switched off the power to avoid to wasting electricity.
- 3. After using sprayer. It should be charged. Then deposited. If not using the sprayer for a long time. Please charge the battery approx. once every second month to retain life-span of batter.
- 4. After using sprayer. Please keep outside and inside of sprayer clean.
- 5. Keep the sprayer in the shady place. Don't store the sprayer under direct sunlight
- 6. Please keep no residue of insecticide, fertilizer or herbicide at bottom of tank, keep bottom dry so as to avoid corrosion.

#### SAFETY WARNING

If you are using the sprayer with hazardous or poisonous liquid, use only with directions supplied by the manufactured of the hazardous or poisonous liquid. Please clean the sprayer thoroughly after use.

**Note:** Please clean tank inside by clear water after spraying each time. Please using filter when put into water.

**STORE:** Please clean the pump, then charge 10-15 hours, keep it at day shady place.

**WARNING:** Don't let battery without power, otherwise it can't charge next time, As battery with self discharge function, please recharge after two or three months.

SL NO	PART NO	PHOTOS	DESCRIPTION
1	GP-BSDP-20MS-01		Tank cap
2	GP-BSDP-20MS-02		Strainer
3	GP-BSDP-20MS-03	9	Tank
4	GP-BSDP-20MS-04		Backrest
5	GP-BSDP-20MS-05		Hose
6	GP-BSDP-20MS-06		Inner filter
7	GP-BSDP-20MS-07		Elbow
8	GP-BSDP-20MS-08		Double pump

SL NO	PART NO	РНОТО	DESCRIPTION
9.1	GP-BSDP-20MS-9.1		Indian 8 holes nozzle
9.2	GP-BSDP-20MS-9.2		Indian single nozzle
9.3	GP-BSDP-20MS-9.3		Indian 4 holes nozzle
10	GP-BSDP-20MS-10		Gun handle
11	GP-BSDP-20MS-11		Trigger
12	GP-BSDP-20MS-12	LD11	Indian lance 1 brass end 2 plastic end
13	GP-BSDP-20MS-13		Spraying gun-Zinc alloy
14	GP-BSDP-20MS-14		2.0A Charger

SL NO	PART NO	PHOTOS	DESCRIPTION
15	GP-BSDP-20MS-15	1-	Regulator
16	GP-BSDP-20MS-16		Double switch with wire
17	GP-BSDP-20MS-17		Charging socket with wire
18	GP-BSDP-20MS-18		Volt meter with wire
19	GP-BSDP-20MS-19	-	12V/14AH battery real is 12AH
20	GP-BSDP-20MS-20		Bottom plate
21	GP-BSDP-20MS-21	III.	Car belt
22	GP-BSDP-20MS-22		Lance clip
23	GP-BSDP-20MS-23		Battery clip

#### **INSPECTION & MAINTENANCE**

For safety, make sure the machine is cleaned every three-months. Before working, make sure to inspect the filter and the nozzle, and ensure there is no impurity. After working, make sure there is no water in the pump and the hose.

If the machine needs to be repaired in the guarantee period, please return the machine to the shop. You need to provide the certificate of purchase in order to repair or get the substitute. Before Packing, the machine should be cleaned, then use closed packaging, packaging should be firm. Store the machine in dry place.

For Transportation safety. The machine should comply with ISTA.



Meaning of crossed -out wheeled dustbin:

Do not dispose of electrical machines as unsorted wase, use separate collection facilities. If electrical machines are disposed of in landfills or dumps, hazardous substance can leak into the groundwater and get into he food chain, damaging your health and well being. When replacing old machines with new ones. The retailer is legally obligated to take back your old machine for disposals at least free of charge.

## WARRANTY CARD

### **CUSTOMER COPY**

DATE	DATE OF DELIVERY	DEALERS OFFICIAL SEAL	DEALERS SIGN
PURCHASERS NAME & ADDRESS			
	CUSTOMER SIGN		
			]
PRODUCT NAME	PRODUCT SERIAL NO.	INVOICE/DN	I NO.
I/Will accept the ter	ms and conditions of warranty as in the warran	nty card	
• • • • • • • • • • • • • • • • • • • •	DEALERS COPY	• • • • • • • • • • • • • • • • • • • •	
DATE	DATE OF DELIVERY	DEALERS OFFICIAL SEAL	DEALERS SIGN
PURCHASERS NAME & ADDRESS			
	— CUSTOMER SIGN		
PRODUCT NAME	PRODUCT SERIAL NO.	INVOICE/DN NO.	
I/Will accept the term	s and conditions of warranty as in the warrant	y card	
	COMPANY COPY	DE 11 EDS OFFICIAL SEAL	DEALERC CICAL
DATE	DATE OF DELIVERY	DEALERS OFFICIAL SEAL	DEALERS SIGN
PURCHASERS NAME & ADDRESS			
	<ul><li>CUSTOMER SIGN</li></ul>		
PRODUCT NAME	PRODUCT SERIAL NO.	INVOICE/DN 1	NO.
	as and conditions of warranty as in the warrant		
I/Will account the term			

1.LIMITED WARRANTY PERIOD: For a period of six months from the date of Sale / delivery of the product which ever is earlier. 2. LIMITED WARRANTY OBLIGATION: Replacement of defective part(s) by authorized dealer are free of charges. If found defective by reasons of defective material / poor workmanship, parts will be replaced and there will be no value re-imbursement. 3. TERMS & CONDITIONS: a. Claims under warranty will be accepted on submission of Warranty Card duly filled and stamped by authorized dealer together with the original purchase document.: b. Shipping / transportation / Incidental charges incurred in replacing defective parts under warranty shall be borne by the purchaser


#### WARRANTY null & void if

- (i) Lack of maintenance, (ii) Incorrect use of the machine or tampering, (iii) Use of non-genuine spare parts, (iv) Usage of acids, solvents, or any flammable materials, (v) Non-usage of filter water / clear water / soft water & using water above 40°C temperature, (vi) While using the pressure washers to draw water which is contaminated with dust & solvents (eg. paint thinners, gasoline, oil, etc.), (vii) Repair done by unauthorized service people, (viii) Those parts subject to wear & tear due to normal operations and plastic parts, rubber items etc., (ix) Loose connections, faulty electrical fixtures & fluctuations in power supply.
- 4. Should any failure occur during or after the warranty period, customer does not have the right to interrupt payment / price discount.
- 5. Incidental or consequential damages like inconvenience commercial loss, loss of tie, mental agony etc.
- 6. Loss of any nature due to operation or non-operation is not covered under warranty.
- 7. All free service are at Dealer's service point only.
- 8. Warranty ceases if service is not done periodically.
- 9. The attached card should be completed and returned to Ratnagiri Impex Pvt. Ltd. for registration immediately after sale / delivery.
- 10. The warranty is void unless you register the warranty card with Ratnagiri Impex Pvt. Ltd.
- 11. The decision of Ratnagiri Impex Pyt. Ltd., in settling the warranty is final in all respects.
- 12. All disputes are subject to Bangalore Courts Jurisdiction
- 1. LIMITED WARRANTY PERIOD: For a period of six months from the date of Sale / delivery of the product which ever is earlier. 2. LIMITED WARRANTY OBLIGATION: Replacement of defective part(s) by authorized dealer are free of charges. If found defective by reasons of defective material / poor workmanship, parts will be replaced and there will be no value re-imbursement. 3. TERMS & CONDITIONS: a. Claims under warranty will be accepted on submission of Warranty Card duly filled and stamped by authorized dealer together with the original purchase document.: b. Shipping / transportation / Incidental charges incurred in replacing defective parts under warranty shall be borne by the purchaser. WARRANTY null & void if
- (i) Lack of maintenance, (ii) Incorrect use of the machine or tampering, (iii) Use of non-genuine spare parts, (iv) Usage of acids, solvents, or any flammable materials, (v) Non-usage of filter water / clear water / soft water & using water above 40°C temperature, (vi) While using the pressure washers to draw water which is contaminated with dust & solvents (eg. paint thinners, gasoline, oil, etc.), (vii) Repair done by unauthorized service people, (viii) Those parts subject to wear & tear due to normal operations and plastic parts, rubber items etc., (ix) Loose connections, faulty electrical fixtures & fluctuations in power supply.
- 4. Should any failure occur during or after the warranty period, customer does not have the right to interrupt payment / price discount.
- 5. Incidental or consequential damages like inconvenience commercial loss, loss of tie, mental agony etc.
- 6. Loss of any nature due to operation or non-operation is not covered under warranty.
- 7. All free service are at Dealer's service point only.
- 8. Warranty ceases if service is not done periodically.
- 9. The attached card should be completed and returned to Ratnagiri Impex Pvt. Ltd. for registration immediately after sale / delivery.
- 10. The warranty is void unless you register the warranty card with Ratnagiri Impex Pvt. Ltd.
- 11. The decision of Ratnagiri Impex Pvt. Ltd., in settling the warranty is final in all respects.
- 12. All disputes are subject to Bangalore Courts Jurisdiction
- 1. LIMITED WARRANTY PERIOD: For a period of six months from the date of Sale / delivery of the product which ever is earlier. 2. LIMITED WARRANTY OBLIGATION: Replacement of defective part(s) by authorized dealer are free of charges. If found defective by reasons of defective material / poor workmanship, parts will be replaced and there will be no value re-imbursement. 3. TERMS & CONDITIONS: a. Claims under warranty will be accepted on submission of Warranty Card duly filled and stamped by authorized dealer together with the original purchase document.: b. Shipping / transportation / Incidental charges incurred in replacing defective parts under warranty shall be borne by the purchaser. WARRANTY null & void if
- (i) Lack of maintenance, (ii) Incorrect use of the machine or tampering, (iii) Use of non-genuine spare parts, (iv) Usage of acids, solvents, or any flammable materials, (v) Non-usage of filter water / clear water / soft water & using water above 40°C temperature, (vi) While using the pressure washers to draw water which is contaminated with dust & solvents (eg. paint thinners, gasoline, oil, etc.), (vii) Repair done by unauthorized service people, (viii) Those parts subject to wear & tear due to normal operations and plastic parts, rubber items etc., (ix) Loose connections, faulty electrical fixtures & fluctuations in power supply.
- 4. Should any failure occur during or after the warranty period, customer does not have the right to interrupt payment / price discount.
- 5. Incidental or consequential damages like inconvenience commercial loss, loss of tie, mental agony etc.
- 6. Loss of any nature due to operation or non-operation is not covered under warranty.
- 7. All free service are at Dealer's service point only.
- 8. Warranty ceases if service is not done periodically.
- 9. The attached card should be completed and returned to Ratnagiri Impex Pvt. Ltd. for registration immediately after sale / delivery.
- 10. The warranty is void unless you register the warranty card with Ratnagiri Impex Pvt. Ltd.
- 11. The decision of Ratnagiri Impex Pyt. Ltd., in settling the warranty is final in all respects.
- 12. All disputes are subject to Bangalore Courts Jurisdiction



FREE SERVICE COUPON (30DAYS/30HRS. WHICHEVER IS EARLIER					
MODEL	SERIAL NUMBER				
PDI DATE	SERVICE NO. PURCHASE BILL NO. DATE				
DEALERS OFFICE SI	EAL				
	1. Check and test the fuel mixture 2. check and clean the air filter 3. Check, clean and adjust the spark plug 5. Check and sparken the cutting tools 7. Start and check the noise, vibration, loosen etc 2. check and clean the air filter 4. Check and adjust the carburetor tuning 6. Product familirisation on usage 8. Routine maintenance and shortage.				
	FREE SERVICE COUPON (30DAYS/30HRS. WHICHEVER IS EARLIER				
MODEL	SERIAL NUMBER				
PDI DATE	SERVICE NO. PURCHASE BILL NO. DATE				
DEALERS OFFICE SEA	OI EIGHTONO				
	1. Check and test the fuel mixture 2. check and clean the air filter 3. Check, clean and adjust the spark plug 5. Check and sparken the cutting tools 6. Product familirisation on usage 7. Start and check the noise, vibration, loosen etc 8. Routine maintenance and shortage.				
FREE SERVICE COUPON (30DAYS/30HRS. WHICHEVER IS EARLIER					
MODEL PDI DATE	SERVICE NO. SERIAL NUMBER PURCHASE BILL NO. DATE				
DEALERS OFFICE SE	AL OPERATIONS				
	1. Check and test the fuel mixture 2. check and clean the air filter 3. Check, clean and adjust the spark plug 5. Check and sparken the cutting tools 6. Product familirisation on usage 7. Start and check the noise, vibration, loosen etc 8. Routine maintenance and shortage.				

DOS



# **DONTS**

- 1. Always read the instruction manual supplied along with the equipments and understand the correct installation and operating procedures before attempting to use the equipments.
- 2. It is important to use the personal protection equipments such as head helmet with visor, ear defenders, goggles, safety gloves, cut resistant shoes, trousers and jackets while operating potentially dangerous machines
- B. Avoid untrained persons using the equipments. Children must not be allowed to handle these equipments
- 4. Always use genuine spares and accessories in repairs and usage to derive maximum life of the equipments.
- 5. Always keep the equipments in good working condition to minimize loss of output as well as to reduce the pollution and save the environment
- 6.Do not use the machine within range of persons unless they wear protective clothing
- 7. Do not operate the machine when fatigued or under the influence of alcohol or drugs
- 8. When the machine is running, please maintain a constant water supply. Without water circulation will damage the sealing rings of the machine.
- 9. For more query kindly contact for our Service Center/Dealer/ franchise

# **Agrimate Army For Pest Control**

ANY WHERE - ANY TIME - ANY CROP
























#### RATNAGIRI IMPEX PVT., LTD.,

Annapurna House, #1 / 1G, 7th Cross, New Guddadahalli

Mysore Road, Bangalore - 560 026

Missed Call: 7393 938 938

Email: ask@agrimart.in