

G 53 TK COMFORT PLUS ALLROAD (K800) Lawnmower



Documents

[Illustrated parts list](#)

[Cylinder head and valve](#)

[Cylinder and crankcase](#)

[Crankcase cover](#)

[Crankshaft and piston](#)

[Starter assy and flywheel](#)

[Carburetor](#)

[Air filter and muffler](#)

[Control lever](#)

[Fuel tank and cover](#)




Illustration Illustrated parts list

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	66060398BR	Traction lever	SN 6190432021			BT5-062-02/11
2	2	3918009R	Washer				
3	1	66070653R	Traction cable				BT5-074-06/14
3	1	66060058CR	Traction cable				BT5-074-06/14
4	1	66070032AR	Guard				
5	7	3914006R	Nut				
6	1	66070954R	Handle				
7	1	66030038	Grommet				
8	2	66060381BR	Pin		SN 6190432020		BT5-062-02/11
9	1	66070233A	Guard kit				
10	8	66070497R	Bearing				
11	1	66060421BR	Handlebar	SN 6190432021			BT5-062-02/11
12	1	66070749	Axle kit				
13	2	66070317R	Tightening handle				
14	1	8202126R	Key				
15	2	66060231	Band				
16	2	3910015R	Screw				
17	4	3933032R	Nut				
18	1	66070437R	Left sprocket	SN 6195164910			BT5-079-04/15
19	1	66110754R	Shutter				
20	1	66072047R	Frame				
21	1	66070457R	Grassbag				
22	2	3024009R	Ring		SN 6190432020		BT5-062-02/11
23	1	66110609A	Kit spring				
24	1	66110026R	Deflector axle				
25	1	66070373AR	Deck				
26	2	3916015R	Washer				
27	2	66070573R	Wheel cover				
28	1	3047027R	Belt				BT5-074-06/14
28	1	3047025R	Belt				BT5-074-06/14
29	1	66070450R	Pulley	SN 6191090552			BT5-066-06/11
30	1	3022020R	Plug				
31	1	66070035BR	Spring				BT5-074-06/14
31	1	66070652R	Spring				BT5-074-06/14
32	2	66070435R	Bushing	SN 6195164910			BT5-079-04/15
33	4	3024012R	Snap ring				
34	7	3916008R	Washer				
35	1	66070022	Rod				
36	1	66070436R	Right sprocket	SN 6195164910			BT5-079-04/15
37	1	66070287AR	Rear axle				
38	3	3806076R	Screw				
39	1	66070755A	Transmission	SN 6191090552			BT5-053-06/09, BT5-066-06/11,

Illustration Illustrated parts list

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
40	5	011200035R	Screw				
41	1	66070286CR	Lever				BT5-055-09/09
42	1	66070469R	Wheel cover				
43	1	66030044	Spacer				
44	1	66070036R	Spring				
45	2	66070729	Wheel kit				
46	2	8202311R	Ring				
47	2	66070574R	Wheel cover				
48	1	66060010R	Roller				
49	1	66060316AR	Brake lever	SN 6190432021			BT5-062-02/11
50	1	3906150R	Screw				
51	2	66060030R	Bushing				
52	1	66030276R	Engine break cable				
53	1	66060384R	Washer				
54	1	66030256R	Hub Ø22,2mm				
55	1	66070440R	Mulching blade				BT5-061-06/10
56	1	66070523R	Cover				
57	2	66030039	Plate				
58	4	3960031R	Screw				
59	6	3801022R	Screw				
60	2	66030049AR	Support				
61	2	3045035R	Retainer washer				
62	2	3045034R	Retainer washer				
63	3	66070228R	Support				
64	1	66070099R	Spring				
65	1	66070133R	Support				
66	2	66070730	Wheel kit				
67	1	66070341AR	Throttle lever				
68	1	3910019	Screw				
69	2	3960072	Screw				
70	1	66070134R	Dashboard				
71	1	66070136R	Throttle cable				
72	1	66070316R	Guard				
73	1	66070291R	Sector				BT5-055-09/09
74	1	3906164R	Screw				
75	4	3035023R	Bearing				
76	1	66070096R	Mulching cap				
77	1	66070380	Labels kit				
78	1	8203374R	Spring				
79	1	66070439A	Lever group				BT5-055-09/09
80	2	3064037	Washer	SN 6190432021			BT5-062-02/11
81	1	66060425R	Handle kit	SN 6190432021			BT5-062-02/11

Illustration Illustrated parts list

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
82	2	66060381BR	Pin	SN 6190432021			BT5-062-02/11
83	2	3024006	Snap ring	SN 6190432021			BT5-062-02/11
84	1	66070521R	Shutter				
85	1	66070466R	Lock				
86	1	66070904	Grassbag kit				





Illustration Cylinder head and valve

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	L66150368	Compensator				
2	2	L66150403	Slide				
3	1	L66150102A	Camshaft assy				
4	1	L66150399	Washer				
5	1	3055123	Spark plug				
6	2	L66150709	Stud	11/2013			
6	2	L66150396	Stud		10/2013		
7	1	L66150221	Head comp.cylinder				
8	4	L66150720	Screw				
9	4	L66150393	Screw				
10	2	L66150350	Plug				
11	1	L66150394	Cover				
12	2	L66150365	Ring				
13	2	L66150366	Valves spring				
14	1	L66150472	Suction/exhaust valve kit				
15	2	L66150241	Stud				
16	1	L66150096	Plate				
17	1	L66150722	Equalizer rod				
18	1	L66150245	Gasket set		10/2013		
18	1	L66150724	Gasket set	11/2013			
19	1	66060414	19 x 21 mm wrench				
20	1	L66150471	Gasket				
21	2	L66150364	Valve				




Illustration Cylinder and crankcase

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150242	Crankcase assy				
2	1	L66150031	Guard				
3	2	L66150251	Screw				
4	1	L66150724	Gasket set	11/2013			
4	1	L66150245	Gasket set		10/2013		
5	1	L66150407	Stud				
6	2	L66150408	Stud				
7	1	L66150410	Reed valve				
8		-	Not available for this product				
9	1	L66150411	Screw				
10	1	L66150257	Spring				
11	1	L66150415	Flyweheel brake				
12	1	L66150244	Cap,breather chamber				
13	2	L66150414	Screw				
14	1	L66150353	Plug				
15	1	L66150419	Gasket				
16	1	L66150246	Tube		10/2013		
16	1	L66150721	Tube	11/2013			
17	1	L66150417	Governor arm shaft				
18	1	L66150035	Washer				
19	1	L66150409	Seal ring				




Illustration Crankcase cover

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150247	Cover				
2	4	L66150047	Screw				
3	1	L66150453	Screw				
4	1	L66150454	Plate				
5	2	L66150455	Bushing				
6	1	L66150456	Screw				
7	1	L66150232	Packing, breather chamber				
8	1	L66150458	Oil cap assy				
9	1	L66150457	Governor				
10	1	L66150283	Gasket				
11	1	L66150462	Oil seal				
12	1	L66150354	Washer				
13	2	L66150357	Plug				
14	1	L66150245	Gasket set		10/2013		
14	1	L66150724	Gasket set	11/2013			
15	1	L66150352	Screw				






Illustration Crankshaft and piston

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150520	Piston ring set				
2	2	L66150075	Snap ring				
3	1	L66150077	Piston pin				
4	1	L66150222	Piston assy				
5	2	L66150078	Connecting rod bolt				
6	1	L66150080A	Connecting rod set				
7	1	L66150355	Bearing				
8	1	L66150083	Crankshaft				
9	1	L66150081	Key				
10	1	L66150424	Washer				




Illustration Starter assy and flywheel

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150248	Starter assy				
2	1	L66150425	Flywheel				
3	1	L66150426	Fan				
4	1	L66150147	Pulley				
5	1	L66150376	Nut				
6	1	L66150427	Spark plug cap				
7	1	L66150428	Engine stop wire				
8	1	L66150429	Ignition coil				
9	1	L66150416	Screw				
10	3	L66150240	Screw				
11	1	L66150234	Cover		10/2013		
11	1	L66150713	Cover	11/2013			
12	1	L66150259	Screw				
13	1	L66150260	Slide				
14	1	L66150270	Starter handle				
15	1	L66150269	Starter rope				
16	1	L66150266	Starter spring				
17	1	L66150265	Pulley				
18	2	L66150263	Pawl				
19	2	L66150264	Spring				
20	1	L66150262	Spring				
21	1	L66150261	Washer				





Illustration Carburetor

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150117A	Insulator				
2	1	L66150143	Carburetor				
3	1	L66150714	Gasket				
4	1	L66150212	Repair kit				
5	1	L66150245	Gasket set		10/2013		
5	1	L66150724	Gasket set	11/2013			



6*




Illustration Air filter and muffler

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150719	Muffler assy	11/2013			
1	1	L66150443	Muffler assy		10/2013		
2	1	L66150715	Air filter	11/2013			
2	1	L66150445	Air filter		10/2013		
3	1	L66150716	Sponge	11/2013			
3	1	L66150255	Sponge		10/2013		
4	1	L66150250	Air filter kit		10/2013		
4	1	L66150717	Air filter kit	11/2013			
5	2	004400959R	Nut				
6	1	L66150245	Gasket set		10/2013		
6	1	L66150724	Gasket set	11/2013			
7	2	L66150185	Nut				




Illustration Control lever

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150168	Adjust. screw				
2	1	L66150169	Spring				
3	1	L66150170	Spring				
4	1	L66150468	Plate				
5	1	L66150172	Screw				
6	1	L66150470	Complete lever				
7	2	L66150464	Screw				
8	1	L66150236	Rod				
9	1	L66150237	Spring				
10	1	L66150178	Throttle rod				
11	1	L66150180	Spring				
12	1	L66150182	Control lever				
13	1	L66150382	Screw				
14	1	L66150185	Nut				




Illustration Fuel tank and cover

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150437	Cap				
2	1	L66150253	Complete tank				
3	1	L66150185	Nut				
4	1	L66150438	Washer				
5	1	L66150251	Screw				
6	1	L66150439	Filter				
7	1	L66150239	Stud				
8	1	L66150440	Clip				
9	2	L66150435	Clip				
10	1	L66150432	Tube				